

## Yaesu FT Dx-9000 Maintenance Menu

1. Turn your rig off with the front panel switch.
2. Hold the "antenna 1", "antenna 3" and "rx antenna" buttons in, and turn the rig on.



3. The rig will come up in the Maintenance menu



4. Use the VFO A dial to swing through the items.
5. There are four banks called; A01 to A45, B01 to B45, C01 to C72 and 01 to 06. Some one has sub-index (for example C17a, C17b up to C17f).
6. The value for every item is show below and somekind of "item meaning" at the right side.
7. Change the value with the VFO B dial.
8. To save your new settings; hold the Menu button down for two seconds.